

Installation Bar Code Scanner Olympia LS 7000 Anschluss Plug & Play

Dieser Scanner LS 7000 wurde für alle Olympia Kassenmodelle vorprogrammiert. Die Grundeinstellung des Scanners darf beim Benutzen mit Olympia Kassen nicht verändert werden. An Olympia Kassen müssen keine Einstellungen gemacht werden. Änderungen am Setup des Scanners können zu Funktionsstörungen führen.

VERBINDUNGEN

Wählen Sie entsprechen Ihrem Kassenmodell eines der 3 beiliegenden Anschlusskabel.

Olympia Modelle

CM 911/912 / CM 941/942/F / CM 960/962-SF / CM 980 F/SF / Touch 110



Anschlusskabel: PS 2

Olympia Modell touch 200



Anschlusskabel: USB



Das Anschlusskabel RS 232
benötigt.

Anschluss geprüft z.B. für QUORION Kassen.

wird nicht für Olympia Kassen

Installation of the Bar Code Scanner Olympia LS 7000

The connectivity is Plug & Play version.

The scanner LS 7000 is prepared to work with the Olympia Cash Registers. The settings of the scanner LS 7000 shall not be changed! There is also no need for any changes on the Olympia cash registers. Any changes on the scanner or cash register settings may cause malfunction.

Connections:

Please select one of the next two cables for your Olympia Cash Register:

Olympia Model:

CM 911/912 / CM 941/942/F / CM 960/962-SF / CM 980 F/SF / Touch 110



Connection cable: PS 2

Olympia Model:

Touch 200



Connection cable: USB

The connection cable RS 232 is not needed for Olympia cash registers but you can use it for QUORION cash registers (example).

